
SYSTEMS INC
t: +1 315 463 1585
f: +1 315 463 9557
www.datacomsystems.com

Upgrading the Network (Security) Engine on Datacom devices.

Load the current version of .NET from Microsoft.


Install and run the program Flashutils. Please make sure to run as administrator

First, select the Product model number to upgrade in the Product Selection ares.



Next, enter the device IP address.

Click the browse button. A window will pop up asking you to choose whether you will upgrade the Microprocessor or the Network Engine.



DATACOM SYSTEMS INC

9 Adler Drive
East Syracuse, NY 13057


t: +1 315 463 1585
f: +1 315 463 9557

www.datacomsystems.com

The Network Engine will upgrade the Security Version. The Microprocessor will upgrade the firmware version.

Next, select the file to use.

\




Once you have finished each of the previous steps, click program.

DATACOM SYSTEMS INC


9 Adler Drive
East Syracuse, NY 13057

t: +1 315 463 1585
f: +1 315 463 9557


www.datacomsystems.com



You will be required to provide login information for the device.



You will see this screen when finished.



Log back into your device and run the “show” command to confirm your changes.

*After upgrading the Security Engine and logging back into device, then repeat all of the above steps, but select Microprocessor and select the current Micro upgrade file dsi_micro_CFG_Ver_x_x_x

(at the time of this writing the file version is dsi_micro_CFG_Ver_2_1_4)